



**NOTES:** CUT-OUT MODELS ARE FOR AUTOMOBILES WITH 16 INCH OR LARGER WHEELS - BECAUSE OF DIFFERENCES IN WHEEL TAPERS, IT IS POSSIBLE THAT THE TALLER FSBC UNIT MAY FIT ON THE OUTER BRAKE PAD AS WELL. USE CUT-OUTS TO DETERMINE FITTING AND ORDER BASED ON THE MODEL NUMBER PRINTED ON THE CUT-OUT.

**DIRECTIONS:** COPY OR PRINT ONTO CARD STOCK. MEASURE INDICATED DIMENSIONS AFTER PRINTING TO MAKE SURE SCALE IS 1 TO 1. CUT ALONG DARK LINES - FOLD TABS ALONG DOTTED LINES TO SIMULATE HEATSINK HEIGHT. INSTALL BETWEEN BRAKE PAD AND CALIPER PISTON WITH PRINTED SIDE TOWARDS CALIPER PISTON. RE-INSTALL WHEEL AND CHECK CLEARANCE - MUST HAVE AT LEAST 3/32" CLEARANCE AT ALL POINTS.

**MAKE SURE WHEEL BALANCING WEIGHTS WILL NOT HIT THE FSBC WHEN INSTALLED! REMOVE CUT-OUTS BEFORE DRIVING!**